

ACCESSORI PER SEZIONATORI SM - SMB - SMF / ACCESSORIES FOR SM - SMB - SMF LOAD BREAK SWITCHES

MANOVRA DIRETTA / DIRECT HANDLE

Sezionatore / Switch disconnecter	Modello / Type	Codici di ordinazione / Ordering codes
SM3 da/from 16 a/to 125A	SM-DH3	4148679
SM3 da/from 16 a/to 125A	SM-DH3 Y/R Emergenza / Emergency	4148681
SM4 da/from 16 a/to 125A	SM-DH4	4148680
SM4 da/from 16 a/to 125A	SM-DH4 Y/R Emergenza / Emergency	4148682
SMB da/from 125 a/to 160A	SMB-DH 3P/4P da/from 125 a/to 160A	4148683
SMB da/from 125 a/to 160A	SMB-DH 3P/4P Y/R da/from 125a 160A E	4148684

MANOVRA BLOCCO PORTA / DOOR INTERLOCK HANDLE

Sezionatore / Switch disconnecter	Modello / Type	Codici di ordinazione / Ordering codes
SM da/from 16 a/to 125A - SMF da/from 16 a/to 32A	SM-HA (1)	4148764
SM da/from 16 a/to 125A - SMF da/from 16 a/to 32A	SM-HA Y/R (1)	4148765
SMB da/from 125 a/to 160A - SMF da/from 16 a/to 32A	SM-HB (2)	4148762
SM da/from 125 a/to 160A - SMF da/from 16 a/to 32A	SM-HB Y/R (2)	4148763
SMB da/from 200 a/to 250A - SMB da/from 200 a/to 250A	SM-HC (3)	
SMB da/from 200 a/to 250A - SMB da/from 200 a/to 250A	SM-HC Y/R (3)	

ALBERO / SHAFT

SM da/from 16 a/to 125A	manovra / handle SM-HA	SM-SA100	4148795
SM da/from 16 a/to 125A	manovra / handle SM-HA	SM-SA200	4148796
SM da/from 16 a/to 125A	manovra / handle SM-HA	SM-SA300	4148797
SMB da/from 125 a/to 250A	manovra / handle SM-HE	SM-SB100	4148792
SMB da/from 125 a/to 250A	manovra / handle SM-HE	SM-SB200	4148793
SMB da/from 125 a/to 250A	manovra / handle SM-HE	SM-SB300	4148794

CONTATTI AUSILIARI / AUXILIARY CONTACTS

SM da/from 16 a/to 125A		SM-T11	4148870
SM da/from 16 a/to 125A		SM-T22	4148871
SMB da/from 125 a/to 160A		SMB-T11	4148872
SMB da/from 125 a/to 160A		SMB-T22	4148873
SMB da/from 200 a/to 250A		SMC-T11	
SMB da/from 200 a/to 250A		SMC-T22	

KIT PER MONTAGGIO SU PORTA / DOOR MOUNTING KITS

SM da/from 16 a/to 125A		SM - DM	4148677
SM da/from 16 a/to 125A		SM - DM Y/R	4148678

FISSAGGIO CON VITI / SCREW FIXING BASE

SM3 da/from 16 a/to 125A - SMF3 da/from 16 a/to 32A		SM-FB3	4148678
SM4 da/from 16 a/to 125A - SMF4 da/from 16 a/to 32A		SM-FB4	4148679

KIT DI COMMUTAZIONE / CHANGE-OVER KIT

SM da/from 16 a/to 125A		SM-KC 1-2 (senza di posizione di 0) / (without 0 position)	4148685
SM da/from 16 a/to 125A		SM-KC 1-0-2	4148686

ACCESSORIO DI PARALLELO / PARALLEL KITS

SM da/from 16 a/to 125A	SM-KP66	Albero centrale / Central shaft	4148687
SM da/from 16 a/to 125A	SM-KP80	Albero centrale / Central shaft	4148688
SM da/from 16 a/to 125A	SM-KP104	Albero centrale / Central shaft	4148689
SM da/from 16 a/to 125A	SM-KP126	Albero centrale / Central shaft	4148690
SM da/from 16 a/to 125A	SM-KP66S	Albero laterale / Side shaft	4148692
SM da/from 16 a/to 125A	SM-KP80S	Albero laterale / Side shaft	4148693
SM da/from 16 a/to 125A	SM-KP104S	Albero laterale / Side shaft	4148694
SM da/from 16 a/to 125A	SM-KP126S	Albero laterale / Side shaft	4148695

ESPANSIONI PER BANDELLE PER SEZIONATORI SMB / SPREADERS FOR SMB BREAK SWITCHES

SMB3 da/from 125 a/to 250A		SMB-BR3	4148675
SMB4 da/from 125 a/to 250A		SMB-BR4	4148676

(1) IP66

(2) IP66-IP67

(3) IP65